

Figure 2: P141 Feeder Management Relay; directional phase overcurrent and earth fault (8 I/P & 7 O/P)




Figure 6: P142 Feeder Management Relay; directional phase overcurrent and earth fault with autoreclose (8 I/P & 15 O/P)




Figure 10: P143 Feeder Management Relay; directional phase overcurrent and SEF with autoreclose and check synchronising (16 I/P & 14 O/P)